

BALL COALESCENT  
 BOYA COALESCENTE



O-RING INCLUDED  
 JUNTA INCLUIDA

COALESCENT OIL SEPARATOR  
 SEPARADOR DE ACEITE COALESCENTE

**BALL COALESCENT-SAC/SACR (SPARE)**  
**BOYA COALESCENTE-SAC/SACR (REPUESTO)**  
 HFC / CO<sub>2</sub> / R410A

MODEL OIL SEPARATOR MODELO SEPARADOR DE ACEITE	MODEL BALL MODELO BOYA	CODE CÓDIGO
SAC-4 1 5/8" / SARC-4 1 5/8"	Spare Flange—Float Repuesto Brida—Boya	A-004156
SAC-5 2 1/8" / SARC-5 2 1/8"		
SAC-6 2 5/8" / SARC-6 2 5/8"		
SAC-7 3 1/8" / SARC-7 3 1/8"		
SAC-8 3 1/8" / SARC-8 3 1/8" <b>NEW</b>		

**NH<sub>3</sub> COALESCENT BALL-SAC/SACR (SPARE)**  
**BOYA COALESCENTE NH<sub>3</sub> -SAC/SACR (REPUESTO)**

MODEL OIL SEPARATOR MODELO SEPARADOR DE ACEITE	MODEL BALL MODELO BOYA	CODE CÓDIGO
SAC-4-NH <sub>3</sub> 1 5/8" / SARC-4-NH <sub>3</sub> 1 5/8"	Spare Flange—Float -NH <sub>3</sub> Repuesto Brida—Boya-NH <sub>3</sub>	A-004202
SAC-5-NH <sub>3</sub> 2 1/8" / SARC-5-NH <sub>3</sub> 2 1/8"		
SAC-6-NH <sub>3</sub> 2 5/8" / SARC-6-NH <sub>3</sub> 2 5/8"		
SAC-7-NH <sub>3</sub> 3 1/8" / SARC-7-NH <sub>3</sub> 3 1/8"		
SAC-8-NH <sub>3</sub> 3 1/8" / SARC-8-NH <sub>3</sub> 3 1/8" <b>NEW</b>		

SECTIONAL OIL SEPARATOR  
 SEPARADOR DE ACEITE DESMONTABLE

**BALL COALESCENT -SA (SPARE)**  
**BOYA COALESCENTE-SA (REPUESTO)**  
 HFC / CO<sub>2</sub> / R410A

MODEL OIL SEPARATOR MODELO SEPARADOR DE ACEITE	MODEL BALL MODELO BOYA	CODE CÓDIGO
SA-5 1 5/8" / SA-5-45 1 5/8"	Spare Flange—Float Repuesto Brida—Boya	A-004156
SA-5 2 1/8" / SA-5-45 2 1/8"		
SA-8 1 5/8" / SA-8-45 1 5/8"		
SA-8 2 1/8" / SA-8-45 2 1/8"		
SA-13 2 5/8" / SA-13-45 2 5/8"		
SA-25 3 1/8" / SA-25-45 3 1/8"		